

TO FIT SIZE CHART

*Measurements refer to body size, not garment dimensions



S180X - UNISEX MICRO LITE TEAM JACKET

25.02.2016

	XS	S	M	L	XL	2XL	3XL	4XL
Full chest in inches*	34	38	41	44	47	50	53	56
Full chest in cm*	86,36	96,52	104,14	111,76	119,38	127	134,62	142,24
German clothing size (men)	44	48	50	54	56	60	64	66

HOW TO MEASURE CHEST: Place the tape measure across the back, underneath the arms and then across the fullest part of the chest.

1 Inch = 2,54 cm